

Contents

1. Get to know your cutter 2

1.1 Swapping tool heads 2



www.keencut.com
+44 (0) 1536 263158 sales@keencut.co.uk (UK HQ)
+1 (716) 748 6203 sales@keencut.com (US sales)

The world’s finest cutting machines


Scan the QR code or
[click here to view this document online >](#)




1. Get to know your cutter

1.1 Swapping tool heads

See how to swap tool heads in this video >




Pull and remove end stop.




Slide the cutting head to the right.






Lift up the head to remove it.



Insert the cutting head of your choice, and slide it to the left.
More than one tool can be mounted on the cutter bar if required.



Always replace the end stop.

